

WOMEN'S PLEATED-FRONT PANT SPECIFICATIONS

SIZE	WAIST (+ OR - 1/2")	HIPS (+ OR - 1/2")	INSEAM
4	26	41 1/2	33 1/2 inches or shorter
6	27	42 1/2	33 1/2 inches or shorter
8	28	43 1/2	33 1/2 inches or shorter
10	29	44 1/2	33 1/2 inches or shorter
12	30 1/2	46	33 1/2 inches or shorter
14	32	47 1/2	33 1/2 inches or shorter
16	33 1/2	49	33 1/2 inches or shorter
18	35 1/2	50 1/2	33 1/2 inches or shorter
20	37 1/2	52 1/2	33 1/2 inches or shorter
22	39 1/2	54 1/2	33 1/2 inches or shorter
24	41 1/2	56 1/2	33 1/2 inches or shorter
26	43 1/2	58 1/2	33 1/2 inches or shorter
28	45 1/2	60 1/2	33 1/2 inches or shorter
30	47 1/2	62 1/2	33 1/2 inches or shorter
32	49 1/2	64 1/2	33 1/2 inches or shorter
34	51 1/2	66 1/2	33 1/2 inches or shorter

All measurements are in inches.

HOW TO MEASURE

WAIST: Measure just above hipbone at the natural waistline. Stand relaxed, not holding your stomach in, as this will result in an inaccurate measurement.

INSEAM: Measure from base of crotch to top edge of shoe, standing upright.

Try to wear the shoe that will be worn with the pants.

HIPS: Measure around the fullest part of the buttocks.